







































































Original	Substituto	Original	Substituto
 Power	 Power	 Green	 Green / APP / Repeat
 Source	 AV / Input / RDS	 Yellow	 Yellow / YouTube / Repeat
 Mute	 Mute / Dimmer	 Subtitle	 Subtitle / EQ
 1	 1	 Blue	 Blue / Prime Video / Random
 2	 2	 Audio	 Audio / Lang I/II
 3	 3	 FAV	 Fav / Marker / PC
 4	 4	 Up	 Up
 5	 5	 Stop	 Stop / Hold
 6	 6	 Play	 Play / Slow
 7	 7	 Pause	 Pause / Step / Freeze
 8	 8	 Left	 Left
 9	 9	 Enter	 OK
 0	 0	 Right	 Right
 Nothing	 Info / Angle	 Mode	 Picture / Format
 Scan	 Smart / List	 Setup	 Setup / OPT /
 Red	 Red / Netflix / Search	 Down	 Down
 Zoom	 Zoom / Size	 TTX	 Text / Goto





	Original	Substituto	Original	Substituto
	EPG	GUIDE EPG Guide / EPG / -/--		
	REPEAT	SHIFT + APP Repeat Shift + Green / APP /		
	TV/RADIO	PROGRAM TV/RADIO TV/Radio /		
	I<<	PRESET- I<< / Preset-		
	>>I	PRESET+ >>I / Preset+		
	EXIT	CLEAR EXIT Exit / Cancel / Clear		
	DISPLAY	MEDIA DISPLAY Display / Media		
	<<	TUNE- << / Tune-		
	>>	TUNE+ >> / Tune+		

