







































































Original	Substituto	Original	Substituto
 Power	 Power	 Internet / PIP	 Media
 HDM / Control	 HOME SMART	 1	 1
 Rec	 REC MODE	 2	 2
 Stop	 Stop	 3	 3
 Play	 PLAY MODE	 4	 4
 Pause	 Pause	 5	 5
 <<	 <<	 6	 6
 >>	 >>	 7	 7
 1/2 <<	 1/2 <<	 8	 8
 1/2 >>	 1/2 >>	 9	 9
 Red/ Zoom ↑ ↓	 Red	 0	 0
 Green/ Repeat / ↓	 Green	 Text	 Text
 Yellow Root	 Yellow	 Info	 Info
 Blue/ Title	 Blue	 Source	 AV
 Screen	 PICTURE FORMAT	 OK	 OK
 Lang	 SOUND DUAL	 Up	 Up
 Subtitle	 AD SUBT	 Down	 Down



