




Original	Substituto
Standby	Power
Source	AV
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	Guide
Display	Info
Picture	Shift + Format
Sleep	Sleep
Mode	Smart

Original	Substituto
Return	Back
Up	Up
Left	Left
Menu	Menu
Menu	Ok
Right	Right
Down	Down
Mute	Mute
Zoom	Eject
Nicam/A2	Dual
Sound	Shift + Dual
Text	Text
Cancel	Exit
Red	Red
Green	Green
Yellow	Yellow
Cyan	Blue





Original	Substituto	Original	Substituto
MIX	Mix	SHIFT + REPEAT TEXT	Shift + Text
SIZE	Size	PICTURE FORMAT	Format
HOLD	Hold	[Stop Button]	Stop
REVEAL	Reveal	APP MEDIA	Media
INDEX	Index	SETTINGS OPT	Options
SUBPAGE	Subpage	AD SUBT	Subt
[Up Arrow]	Up	+ CH	Ch +
[Down Arrow]	Down	CH -	Ch -
[Left Arrow]	Left	VOL -	Vol -
[Right Arrow]	Right	+ VOL	Vol +

Original	Substituto	Original	Substituto

