



Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute
	Exit		Exit
	Goto / Text		Text
	Audio / I/II		Dual
	Display		Info
	Sleep		Sleep
	P-		Ch -
	P+		Ch +
	V-		Vol -
	V+		Vol +
	Source		AV
	TV Menu		Menu
	Up		Up
	Left		Left
	Enter		Ok
	Right		Right
	Down		Down
	PMode		Format
	SMode		Shift + Dual
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/- / +10		Shift + Guide
	Recall / Prog		Back
	Red / D.Setup		Red
	Red / D.Setup		Options



