



| Original  | Substituto | Original  | Substituto                  |
|---|------------|---|-----------------------------|
|      | Power      |      | Power                       |
|      | Mute       |      | Mute / Dimmer               |
|      | Audio      |      | Audio / Lang I/II           |
|      | Sub        |      | Subtitle / EQ               |
|      | TXT        |      | Text / Goto                 |
|      | Recall     |      | Back / Return               |
|      | Red        |      | Red / Netflix / Search      |
|      | Green      |      | Green / APP / Repeat        |
|      | Yellow     |      | Yellow / YouTube / Repeat   |
|      | Blue       |      | Blue / Prime Video / Random |
|     | i          |     | Info / Angle                |
|    | Menu       |    | Menu / Home                 |
|    | Up         |    | Up                          |
|    | Left       |    | Left                        |
|    | OK         |    | OK                          |
|    | Right      |    | Right                       |
|    | Down       |    | Down                        |
|    | EPG        |    | EPG                         |
|    | Exit       |    | Exit / Cancel / Clear       |
|    | Vol+       |    | Vol+                        |
|    | Vol-       |    | Vol-                        |
|    | Fav        |    | Fav / Marker / PC           |
|    | List       |    | Smart / List                |
|    | CH+        |    | CH+ / Page+                 |
|    | CH-        |    | CH- / Page-                 |
|    | 1          |    | 1                           |
|    | 2          |    | 2                           |
|   | 3          |   | 3                           |
|  | 4          |  | 4                           |
|  | 5          |  | 5                           |
|  | 6          |  | 6                           |
|  | 7          |  | 7                           |
|  | 8          |  | 8                           |
|  | 9          |  | 9                           |





| Original |   | Substituto      |   | Original |  | Substituto |  |
|----------|---|-----------------|---|----------|--|------------|--|
| 0        | 0 | HDMI - BAT<br>0 | 0 |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |
|          |   |                 |   |          |  |            |  |

