Mandis shop

Philips 996580005296

Original		Substituto	
	Power		Power
	Pause		Pause
COAX	COAX	A	Red
OPTICAL	Optical	B	Green
AUX	AUX	C	Yellow
USB	USB	D	Blue
	Bluetooth	HOME SMART	Smart
HDMI ARC	HDMI Arc	APP MEDIA	Media
	I<		I<<
	Play	PLAY MODE	Play
	>I		>>I
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
	Mute	MUTE	Mute
+ BASS	Bass+		Up
BASS –	Bass-		Down
+ TREBLE	Treble+	+ CH	Ch +

Original		Substituto	
TREBLE –	Treble-	CH –	Ch -
VOICE	Voice	SOUND DUAL	Dual
MOVIE	Movie	FAV PRE-CH	Pre Ch
MUSIC	Music	GUIDE	Guide
AUDIO SYNC +	Audio Sync+		Right
– AUDIO SYNC	Audio Sync-		Left
NIGHT ON	Night On	3	3
OFF NIGHT	Off Night	1	1

https://ordered.ro/p/Philips/1363627-mando-substituto-para-Philips-996580005296.html