Mandis shop

RC- 970

Original	Substituto
Power	Power
FM/AM	Display / Media
Stop	Stop / Hold
Play	Play / Slow
Pause	Pause / Step / Freeze
>>I / Tuning Up	>> / Tune+
>>I / Tuning Up	>>I / Preset+
MP3 Folder/Preset Up	CH+ / Page+
Function (Tuner/CD/AUX)	Smart / List
I<< / Tuning	<< / Tune-
I<< / Tuning	I<< / Preset-
MP3 Folder/Preset Down	CH- / Page-
Sleep	Sleep / Timer
MP3	Sound / Title
PTY Repeat	Green / APP / Repeat
RDS Shuffle	AV / Input / RDS
RDS Shuffle	Blue / Prime Video / Random

Original	Substituto
Memory/Clock Set	Setup / OPT /
Timer	Shift + Sleep / Timer
Muting	Mute / Dimmer
Bass+	Right
Treble+	Up
Volume+	Vol +
Bass-	Left
Treble-	Down
Volume-	Vol -

https://ordenerdo.pt/p/Teac/10625315-mando-substituto-para-Teac-RC970.htm