Mandis shop

LaCie LACIE001

Original		Substituto	
	Power		Power
	Mute	MUTE	Mute
	Home	HOME SMART	Smart
	Vol+	+ VOL	Vol +
	Vol-	VOL −	Vol -
	Up		Up
	Left		Left
	OK	OK	Ok
	Right		Right
	Down		Down
	i	DISPLAY INFO	Info
	:≡	-/-- GUIDE	Guide
	Settings	SETTINGS OPT	Options
	Settings	TOP MENU MENU	Menu
	Stop		Stop
	Rec	REC MODE	Rec
	Play/Pause	PLAY MODE	Play

Original		Substituto	
	Play/Pause		Pause

https://controleremoto.pt/pt/LaCie/1064001-49753-comando-de-substituicao-para-LaCie-Lacie001.html