Mandis shop

MORE001

Original		Substituto	
ON/OFF	On/Off		Power
TIMING	Timing	TIMER SLEEP	Sleep / Timer
NIGHT LIGHT	Night Light	CLEAR EXIT CANCEL	Exit / Cancel / Clear
MUSIC	Music	LANG I/II AUDIO	Audio / Lang I/II
COLOR LIGHT	Color Light	RETURN BACK	Back / Return
ROTATION	Rotation	MEDIA DISPLAY	Display / Media

Original	Substituto

https://controleremoto.pt/pt/Moredig/1066444-96449-comando-de-substituicao-para-Moredig-MORE001.html