Mandis shop

Sinudyne 07660BM440

Original		Substituto	
	Power		Power
EJECT	Eject	SURROUND	Eject / Surround
TIMER REC	Timer REC	SHIFT + REC MODE	Shift + Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
CHANNEL TRACKING	Channel	CH+ PAGE	CH+ / Page+
0 AV	0/AV	HDMI-SAT 0	0
TV/VCR	TV/VCR	PROGRAM TV/RADIO	TV/Radio /
	Channel Tracking	CH- PAGE	CH- / Page-
SPEED SP/LP	Speed/SP/LP	SIZE ZOOM	Zoom / Size

Original		Substituto	
CALL	Call	TITLE SOUND	Sound / Title
REC/OTR	REC/OTR	REC MODE	Rec / Rec Mode
SLOW	Play/Slow+	SLOW	Play / Slow
PAUSE/STILL	Pause/Still	STEP-FREEZE	Pause / Step / Freeze
	<<</<	TUNE-	<< / Tune-
	>>/>	TUNE+	>> / Tune+
PROGRAM	Program	TOP MENU D.MENU	D.Menu / Top
	Stop/Slow-	HOLD	Stop / Hold
ENTER	Enter	OK	OK
MENU	Menu	HOME MENU	Menu / Home
CANCEL	Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
INDEX	Index	LIST SMART	Smart / List
ATR	ATR	MEDIA DISPLAY	Display / Media
CLOCK/ COUNTER	Clock/Counter	TIMER SLEEP	Sleep / Timer
ZERO RETURN	Zero/Return	RETURN BACK	Back / Return
COUNTER RESET	Counter/Reset	FORMAT PICTURE	Picture / Format
AUDIO SELECT	Audio Select	LANG I/II AUDIO	Audio / Lang I/II

https://ordered.com/p/Sinudyne/1675-500-mando-substituto-para-Sinudyne-07660BM440.htm