Mandis shop

RC-601

Original		Substituto	
IN	IN		Up
IN	IN	CH	CH+ / Page+
IN	IN		Right
IN	IN	VOL	Vol+
OUT	OUT		Down
OUT	OUT	CH	CH- / Page-
OUT	OUT		Left
OUT	OUT	VOL	Vol-

Original	Substituto

https://controleremoto.pt/pt/LAVA/1068113-27978-comando-de-substituicao-para-LAVA-RC-601.html