Mandis shop

CABASSE

Original		Substituto	
	Power		Power
	Mute	DIMMER MUTE	Mute / Dimmer
	[)(]	SURROUND	Eject / Surround
HDMI IN	HDMI In	HDMI - SAT 0	0
+	+	+ VOL	Vol+
	[+]	FORMAT PICTURE	Picture / Format
TV ARC	Tv ARC	TV 1	1
-	-	VOL -	Vol-
	Sleep	TIMER SLEEP	Sleep / Timer
S/PDIF	S/PDIF	OPT-TOOLS SETUP	Setup / OPT /
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
	♫	TITLE SOUND	Sound / Title
	Bluetooth	BLUETOOTH 9	9
	Receptor	USB 8	8
STD	STD	EQ SUBTITLE	Subtitle / EQ

Original	Substituto

https://controleremoto.pt/pt/ORANGE/1066294-94130-comando-de-substituicao-para-ORANGE-CABASSE.html