Mandis shop

Philips 996510059208

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Power | Power | | |
| AUX | 7 | | |
| AUX | Red / Netflix / Search | | |
| Coax | Yellow / YouTube / Repeat | | |
| Audio In | Green / APP / Repeat | | |
| Optical | Blue / Prime Video / Random | | |
| Bass+ | Up | | |
| Vol + | Vol + | | |
| Treble+ | Right | | |
| Bass- | Down | | |
| Vol - | Vol - | | |
| Treble- | Left | | |
| Mute | Mute / Dimmer | | |
| Surr | Eject / Surround | | |
| | | | |
| | | | |
| | | | |

https://ordered.pt/p/Philips/1000-292-mando-substituto-para-Philips-Soundbar-Speaker-996510059208.htm