Mandis shop

Samsung AH59-02631J

Original		Substituto	
	Power		Power
	Source	TIMER AV	AV
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
	Return	RETURN BACK	Back
	Play	PLAY MODE ▶	Play
	Pause	❚❚	Pause
	I <<	⏮	I <<
	>>I	⏭	>>I
SOUND EFFECT	Sound Effect	SOUND DUAL	Dual
3D SOUND	3D Sound	ECO 3D	3D
AUDIO SYNC	Audio Sync	DISC NAV LIST	List
Bluetooth POWER	Bluetooth	HOME SMART	Smart
EQUALIZER WOOFER	Equalizer Woofer	APP MEDIA	Media
DIMMER	Dimmer	PICTURE FORMAT	Format

Original	Substituto

https://orderenter.com/p/Samsung/1553-264-como-substituir-o-para-Samsung-TM51-AH59-02631J.htm