Mandis shop

Sanyo B12618

Original	Substituto
Power	Power
Index	Info / Angle
Play	Play / Slow
>>/ FF	>> / Tune+
<</ REW	<< / Tune-
Stop	Stop / Hold
Pause/ Still	Pause / Step / Freeze
Rec	Rec / Rec Mode
Reset	Red / Netflix / Search
Memory	Green / APP / Repeat
Slow	Shift + Play /
Audio	Audio / Lang I/II
SP/ LP	Picture / Format
Menu/ TV	Menu / Home
Video Plus	Display / Media
PDC	Smart / List
Type	TV/ Radio / Program

Original	Substituto
Channel / Tracking	CH+ / Page+
Channel / Tracking	CH- / Page-
Preset	D. Menu / Top
Clear	Exit / Cancel / Clear
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Input	AV / Input / RDS
0	0
OK	OK

https://ordered.pt/pt/Sanyo/10607-962-mandis-substituicao-para-Sanyo-B12618.htm