Mandis shop

RM-S11

Original		Substituto	
SYSTEM POWER	System Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
DBFB	DBFB	HOME SMART	Smart
TUNER BAND	Tuner Band	SEARCH TV/R	TV/R
RESET +	Preset +	+ CH	Ch +
– PRESE	Preset -	CH –	Ch -
CD	Play CD	PLAY MODE	Play
	Pause CD		Pause
	Stop CD		Stop
	I<< CD		I<<
	>>I CD		>>I
EDIT	Edit CD	APP MEDIA	Media
TAPE	< Tape		Left
	Tape >		Right
	<< Tape		<<
	Tape >>		>>
	Stop Tape	SHIFT +	Shift + Stop

Original		Substituto	
DECK SELECT	Deck Select	OK	Ok
SELECT 1-5	Select 1-5	SETTINGS OPT	Options
+ VOL	Vol +	+ VOL	Vol +
VOL –	Vol -	VOL –	Vol -

https://ordered.pt/pt/Sony-1605-892-00-substituto-para-Sony-RM-S11.htm