Mandis shop

Yamaha VDQ76100

Original		Substituto	
	Power		Power
TV	TV	TV 1	1
OPTICAL	Optical	OPT-TOOLS SETUP	Setup / OPT /
BLUETOOTH	Bluetooth	BLUETOOTH 9	9
ANALOG	Analog	MEDIA DISPLAY	Display / Media
CLEAR VOICE	Clear Voice	CLEAR EXIT CANCEL	Exit / Cancel / Clear
BASS EXT	Bass Ext	LANG I/II AUDIO	Audio / Lang I/II
STEREO	Stereo	TITLE SOUND	Sound / Title
STANDARD	Standard	GOTO TEXT	Text / Goto
MOVIE	Movie	FORMAT PICTURE	Picture / Format
GAME	Game	LIST SMART	Smart / List
+	Subwoofer +	+ CH PAGE	CH+ / Page+
INFO	Info	ANGLE INFO	Info / Angle
+	Volume+	+ VOL	Vol +
DIM	Dim	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
SUBWOOFER	Subwoofer -	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer

Original		Substituto	
VOLUME	Volume-	VOL −	Vol -

https://ordered.pt/pt/Yamaha/1068957-mandos-substituicao-para-Yamaha-VDQ76100.htm